



















49UN7100PUA	55UN6950ZUA	60UN6951ZUA	70UN6950ZUA
49UN7000PUB	55UN6951ZUA	60UN7000PUB	70UN7070PUA
50UN7000PUC	55UN7100PUA	65UN6950ZUA	70UN7100PUA
50UN6950ZUF	55UN7000PUB	65UN6951ZUA	
50UN6951ZUF	60UN6950ZUA	65UN7100PUA	



1
50/55UN69*
49/50/55UN70*
49/55UN71*



1
60/65/70UN69*
60/70UN70*
65/70UN71*








www.lg.com/us/support


ENGLISH
Easy TV Connect Guide
(Animation)

ESPAÑOL
Guía Rápida de Conexión
del televisor
(Sólo en Inglés)

FRANÇAIS
Guide simplifié pour la connexion
du téléviseur (Offert
en anglais seulement)



A, B, C, D, E : mm (inches / pulgadas / po)
F, G : kg (lbs / libras / lb)



MODELS MODELOS MODÈLES	A		B		C		D		E		F		F-G		Power consumption Consumo de potencia Consommation électrique	
49UN7100PUA	1,108 (43.6)	1 108 (43,6)	705 (27.7)	705 (27,7)	235 (9.2)	235 (9,2)	649 (25.5)	649 (25,5)	79.5 (3.1)	79,5 (3,1)	11.0 (24.2)	11,0 (24,2)	10.9 (24)	10,9 (24)	120 W	
49UN7000PUB	1,108 (43.6)	1 108 (43,6)	708 (27.8)	708 (27,8)	231 (9)	231 (9)	649 (25.5)	649 (25,5)	79.5 (3.1)	79,5 (3,1)	11.1 (24.4)	11,1 (24,4)	10.9 (24)	10,9 (24)	120 W	
50UN6950ZUF 50UN6951ZUF	1,130 (44.4)	1 130 (44,4)	719 (28.3)	719 (28,3)	235 (9.2)	235 (9,2)	663 (26.1)	663 (26,1)	86.3 (3.3)	86,3 (3,3)	11.4 (25.1)	11,4 (25,1)	11.3 (24.9)	11,3 (24,9)	140 W	
50UN7000PUC	1,130 (44.4)	1 130 (44,4)	722 (28.4)	722 (28,4)	231 (9)	231 (9)	663 (26.1)	663 (26,1)	86.3 (3.3)	86,3 (3,3)	11.5 (25.3)	11,5 (25,3)	11.3 (24.9)	11,3 (24,9)	140 W	
55UN6950ZUA 55UN6951ZUA 55UN7100PUA	1,247 (49)	1 247 (49)	783 (30.8)	783 (30,8)	235 (9.2)	235 (9,2)	728 (28.6)	728 (28,6)	88.3 (3.4)	88,3 (3,4)	13.8 (30.4)	13,8 (30,4)	13.7 (30.2)	13,7 (30,2)	140 W	
55UN7000PUB	1,247 (49)	1 247 (49)	787 (30.9)	787 (30,9)	231 (9)	231 (9)	728 (28.6)	728 (28,6)	88.3 (3.4)	88,3 (3,4)	13.9 (30.6)	13,9 (30,6)	13.7 (30.2)	13,7 (30,2)	140 W	
60UN6950ZUA 60UN6951ZUA	1,368 (53.8)	1 368 (53,8)	857 (33.7)	857 (33,7)	255 (10)	255 (10)	796 (31.3)	796 (31,3)	89.1 (3.5)	89,1 (3,5)	19.6 (43.2)	19,6 (43,2)	19.4 (42.7)	19,4 (42,7)	175 W	
60UN7000PUB	1,368 (53.8)	1 368 (53,8)	862 (33.9)	862 (33,9)	269 (10.5)	269 (10,5)	796 (31.3)	796 (31,3)	89.1 (3.5)	89,1 (3,5)	19.8 (43.6)	19,8 (43,6)	19.4 (42.7)	19,4 (42,7)	175 W	
65UN6950ZUA 65UN6951ZUA 65UN7100PUA	1,468 (57.7)	1 468 (57,7)	913 (35.9)	913 (35,9)	255 (10)	255 (10)	854 (33.6)	854 (33,6)	89.9 (3.5)	89,9 (3,5)	21.2 (46.7)	21,2 (46,7)	21.0 (46.2)	21,0 (46,2)	195 W	
70UN6950ZUA 70UN7100PUA 70UN7070PUA	1,578 (62.1)	1 578 (62,1)	984 (38.7)	984 (38,7)	299 (11.7)	299 (11,7)	913 (35.9)	913 (35,9)	91.1 (3.5)	91,1 (3,5)	31.4 (69.2)	31,4 (69,2)	30.7 (67.6)	30,7 (67,6)	225 W	

Power requirement / Alimentación requerida / Alimentation

AC 120 V - 50 / 60 Hz



ENGLISH Read **Safety and Reference**.

ESPAÑOL Leer **Seguridad y Consultas**.

FRANÇAIS Lisez **Sécurité et références**.

ENGLISH
Easy Setup Guide

Please read this manual carefully before operating your set and retain it for future reference.

ESPAÑOL
Guía Rápida de Configuración

Lea atentamente este manual antes de poner en marcha el equipo y consérvelo para futuras consultas.

FRANÇAIS
Guide de configuration rapide

Avant d'utiliser l'appareil, veuillez lire attentivement ce manuel et le conserver pour pouvoir vous y reporter ultérieurement.

⊕ : Depending upon model / Según el modelo / Selon le modèle