

ES-A18A104

Barcode

Hisense



V W 6

Subwoofer | User Manual

Pictures and instructions are only for reference

English



Tips

Before using the subwoofer, please read this manual thoroughly and keep it for future reference. Our company does not assume any liability for any accident arising from violation of the matters of attention and instruction on use in this manual.



In order to avoid an electrical shock or a fire, do not open the cabinet without authorization from Hisense or a professional TV repair person.



Use clean and soft cloths to clean the entire TV set and subwoofer.

【Declaration】

1 Pictures and instructions in the user manual are only for reference, and may be different from appearance of actual products. Please make the object as the standard.

(This statement is applicable throughout this user manual)

2 The subwoofer may have quality upgrade or design improvement without prior notice.



Important Safety Instructions




- a. This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of non-insulated “dangerous voltage” within the product’s enclosure that may be of sufficient magnitude to constitute a risk of electric shock.
 - b. Warning: to reduce the risk of electric shock, do not remove cover (or back) as there are no user-serviceable parts inside. Refer servicing to qualified personnel.
 - c. The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance instructions in the literature accompanying the appliance.
- 1 Read these instructions.
 - 2 Keep these instructions.
 - 3 Heed all warnings.
 - 4 Follow all instructions.

- 5 Do not use this apparatus near water.
- 6 Clean only with dry cloth.
- 7 Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- 8 Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 9 Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- 10 Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- 11 Only use attachments/accessories specified by the manufacturer.
- 12 Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.




- 13 Unplug this apparatus during lightning storms or when unused for long periods of time.
- 14 Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- 15 **WARNING:** To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. The apparatus shall not be exposed to dripping or splashing and that objects filled with liquids, such as vases, shall not be placed on apparatus.
- 16 To disconnect this apparatus from the AC mains completely, disconnect the power supply cord plug from the AC receptacle.
- 17 The MAINS plug is used as the disconnect device, the disconnect device shall remain readily operable.
- 18 Minimum distances around the apparatus for sufficient ventilation.
- 19 The ventilation should not be impeded by covering the ventilation openings with items, such as newspapers, table-cloths, curtains, etc.
- 20 No naked flame source, such as lighted candles, should be placed on the apparatus.


1 Packaged Items



Subwoofer VW6× 1




User manual× 1




Power cord× 1

2 Picture of Subwoofer



Loudspeaker




Button for pairing/
Indicator light

Power supply

3 Powering on the Subwoofer

Power supply

Connect one end of the power cord to subwoofer VW6, and the other end to the power outlet.



4 Pairing Your Subwoofer

Before you begin the pairing process, make sure the subwoofer is plugged in to the power outlet.

- 1 Navigate to the **Sound** menu of the Laser TV. Select **Speakers > TV Speaker**.
- 2 Go to the **Settings** menu. Select **Network > Bluetooth > Subwoofer Pairing**.

3 Press the button on the side of the subwoofer, the white indicator light will blink quickly.

(The subwoofer is in pairing mode when the white light starts to blink quickly. If the subwoofer is not connected, the light will blink slowly.)

4 Select **Start Pairing**. A confirmation message will appear on the screen when it is finished pairing. If it failed to pair, then repeat steps 1-4.

(The device is connected successfully when white indicator is on.)



【Notice】

- During the pairing process, place the subwoofer within **1m** of the TV.
- When in standby mode, the indicator light is amber.
- When the subwoofer is connected to Laser TV, you can press the button on the side of the subwoofer to disconnect it.

5 Specifications

Model	VW6
Product	Subwoofer
Dimension(W×H×D)	360 × 340 × 164 mm
Weight	6.27 kg
Power input	100-240V~50/60Hz 50W
Output power	60W RMS, THD < 1%
Bandwidth	40Hz ~ 250Hz
Operating Temperature	0 ~ 45°C
5.8G Wireless Frequency Range	5743-5840MHz
Max Transmitting Power	20dbm (EIRP)
Wireless transmission distance	15 m (without interference)

6 Other Information

Federal Communication Commission Interference Statement

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

For Products That Transmit RF Energy:

FCC AND IC INFORMATION FOR USERS

This device complies with Part 15 of the FCC rules and Industry Canada's license-exempt RSSs. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation.

FCC/IC Radiation Exposure Statement

This equipment complies with FCC/IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

For All Products with Wireless Operation:

Hereby, HARMAN INTERNATIONAL INDUSTRIES, INCORPORATED, declares that this equipment is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU, ErP 2012/27/EU Directive and RoHS 2011/65/EU Directive. The declaration of conformity may be consulted in the support section of our Web site, accessible from www.harmaninternational.com.

WEEE Notice

The Directive on Waste Electrical and Electronic Equipment(WEEE), which entered into force as European law on 14/02/2014, resulted in a major change in the treatment of electrical equipment at end-of-life.

The purpose of this Directive is, as a first priority, the prevention of WEEE, and in addition, to promote the reuse, recycling and other forms of recovery of such wastes so as to reduce disposal. The WEEE logo on the product or on its box indicating collection for electrical and electronic equipment consists of the crossed-out wheeled bin, as shown below.



This product must not be disposed of or dumped with your other household waste. You are liable to dispose of all your electronic or electrical waste equipment by relocating over to the specified collection point for recycling of such hazardous waste. Isolated collection and proper recovery of your electronic and electrical waste equipment at the time of disposal will allow us to help conserving natural resources. Moreover, proper recycling of the electronic and electrical waste equipment will ensure safety of human health and environment. For more information about electronic and electrical waste equipment disposal, recovery, and collection points, please contact your local city center, household waste disposal service, shop from where you purchased the equipment, or manufacturer of the equipment.